# **UV/LED LAMP BQ-L8 MOLLY NAILS**

Model: BQ-L8

Certificate No.: KTi240621E196C KTi240622S171C

## **TECHNICAL DATA:**

Power: 298W

Nominal input: 100-240V, 50-60Hz

Nominal output: 24V 2A Number of UV LEDs: 72 pcs UV wavelength: 365+405nm




# 1. SAFETY OF USE:

- 1. The lamp should only be powered by an appropriate power source.
- 2. Protect the device from contact with dust, water and other liquids.
- 3. Disconnect the lamp from the power source when the lamp is not in use or when it needs to be cleaned.
- 4. Do not use the lamp:
  - · In damp rooms.
  - · If the power supply has been damaged.
  - · If the device or the connecting cable is damaged.
  - · If the timer buttons do not work.
- 5. The device should not be left on for longer than 60 minutes, as this may reduce its service life. The device is intended for indoor use.
- 6. Making any independent switches and changes to the device is prohibited.
- 7. Opening the device is strictly prohibited and is equivalent to losing the warranty, and the manufacturer does not take responsibility for the correct and safe operation of the device.
- 8. Do not stare directly at the UV light, which can cause eye damage. The lamp uses UV/LED diodes that emit dangerous UV rays. They can also cause skin damage. The skin may be more sensitive to UV rays when taking medication or using cosmetics. If you notice sudden changes on your skin, seek medical advice immediately.
- 9. KEEP AWAY FROM CHILDREN.

### 2. FUNCTION BUTTON CHARACTERIZATION

- 1. Touch screen
- 2. 10s timing button
- 3. 30s timing button
- 4. 60s timing button
- 5. 99s timing button (Low heat mode)
- 6. Adaptor connector



#### 3. HOW TO USE:

- Connect the device to the power supply.
- To turn on the lamp, press the timer button. You can select one of the available timer options 10s/30s/60s/99s (low heat mode), or start working without selecting a time. To do this, put your hand in the device and the exposure will start automatically after the sensor detects movement (maximum exposure time is 99s).
- The display shows the remaining exposure time. 3.
- Follow the instructions for curing the product used. 4
- After using the lamp, unplug it from the mains.



In accordance with art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688), we inform you about the correct handling of waste electrical and electronic equipment:

- 1. It is prohibited to place used electrical and electronic equipment together with other waste this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
- 2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
- 3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
- 4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

#### **IMPORTER**

Molly Lac Michał Szewczyk Piotrkowska 270 90-361 Lodz, Poland uwagi@mollylac.com mollylac.com