# **UV/LED LAMP Sun X5 MAX**

Model: Sun X5 MAX

Certyficate No.: STL2023E0919172C-Y1, STL2023S0919173C-Y1



Power: 150W

Nominal input: 100-240V, 50-60Hz Nominal output: DC 24V-5A Number of UV LEDs: 45 pcs UV wavelength: 365+405nm



# 1. SAFETY OF USE:


- 1. Please read the instruction manual carefully before use.
- 2. Remember that the actual voltage used must correspond to the parameters of the lamp.
- 3. Protect the device from contact with dust, water and other liquids.
- Wipe with mild detergent in case of a dirty surface. Perform this operation with the equipment switched off. (unplug the power cord).
- 5. Do not use the lamp in a damp/wet space or when the air humidity level reaches high values.
- 6. Do not use the lamp in case of a damaged power cable or timer buttons.
- 7. The device is intended for indoor use.
- 8. If you do not use the device for a long time, remove the plug from the outlet.
- Please note that making self-switches and changes to your device is prohibited and equivalent to the loss of warranty.
  The manufacturer does not take responsibility for the correct and safe operation of the device.
- 10. Do not stare directly at the UV light, which can cause eye damage. The lamp uses UV/LED diodes that emit dangerous UV rays. They can also cause skin damage. The skin may be more sensitive to UV rays when taking medication or using cosmetics. If you notice sudden changes on your skin, seek medical advice immediately.
- 11. KEEP AWAY FROM CHILDREN.

## 2. THE SET INCLUDES:

- Lamp body
- · Power cable
- · Removable lamp bottom
- User manual

## 3. FUNCTION BUTTON CHARACTERIZATION:

- 1. Motion sensor
- 2. LCD display
- 3. Input socket for power cable
- 4. 10s timer button
- 5. 30s timer button
- 6. 60s timer button
- 7. 99s timer button (Low Heat Mode)



#### 4. HOW TO USE:

- Connect the device to the power supply.
- To turn on the lamp, press the timer button. You can select one of the available timer options 10s/30s/60s/99s (low heat mode), or start working without selecting a time. To do this, put your hand in the device and the exposure will start automatically after the sensor detects movement (maximum exposure time is 120s).
- Look at the display to control the exposure time. 3.
- Follow the instructions for curing the product used. 4.
- After using the lamp, unplug it from the mains.



In accordance with art. 13 sec. 1 of the Act of 11 September 2015 on used electrical and electronic equipment (Journal of Laws 2015 item 1688), we inform you about the correct handling of waste electrical and electronic equipment:

- 1. It is prohibited to place used electrical and electronic equipment together with other waste this is confirmed by the marking in the form of a "crossed-out bin", which requires selective collection of this type of waste.
- 2. Electrical and electronic devices may contain hazardous substances, mixtures and components, which, after entering the environment, may pose a serious threat to the health and life of humans and living organisms.
- 3. Used electrical and electronic equipment should be transferred only to authorized collection points, the list of which should be included on the website of each Municipal Office.
- 4. Households play a key role in the waste management system for used electrical and electronic equipment due to the possibility of their direct transfer to authorized collection points and the elimination of undesirable social habits resulting in leaving waste equipment in places not intended for this purpose.

#### **IMPORTER**

Molly Lac Michał Szewczyk Piotrkowska 270 90-361 Łódź, Polska uwagi@mollylac.com mollylac.com